



NA2-IO-DPRO

Firmware & DPRO Controller Software
Version History - Issues & Solutions



NEUTRIK



NA2-IO-DPRO - FIRMWARE HISTORY

Device Firmware	
9.14.0.0 11.05.2021	<p>Improvement Add heartbeat support Optimize timeouts for DHCP/ARP/Link-Local IP handling Process mDNS queries correctly</p> <p>Bug fixes Device restarts endlessly in AES mode Bad performance of discovery without DHCP</p>
9.13.1.0 31.03.2021	<p>Improvement Removed metering from SCP communication</p> <p>Bug fixes YSDP communication</p>
9.13.0.0 14.12.2020	<p>Improvement The front LEDs of the device show the same status as on the top panel of DPRO Controller Software In analog mode, highpass LED of channel two indicates his status.</p> <p>Bug fixes Improved in TCP communication Watchdog restarts when Dante Broadway Firmware V4.2.4.2 is in use Buffer overflow in UART drivers</p>
9.12.0.0 23.09.2020	<p>New Feature Control - Crestron Compatibility</p> <p>Improvement Network - Add support for IGMP in DPRO firmware</p>
9.11.0.0 03.02.2020	<p>Factory installed on devices from SN #831295 and higher</p> <p>Improvement Audio - Remove clicking noise on AES/analog switching Audio - Interrupt audio transmission chain for certain events</p> <p>Bug fixes Device reboot when activating phantom power Audio - Phantom ON/OFF causes Audio dropout on both channels Audio - Audio Phase Shift on DPRO Outputs Audio - Modifying parameters in linked mode causes interruptions of audio signal Audio - Enhance switching of phantom power</p>
9.10.0.0 Nov. 2019	<p>Initial release</p>

DPRO CONTROLLER - SOFTWARE HISTORY

Software Version	
2.0.0.0 11.05.2021	<p>New features</p> <ul style="list-style-type: none">New menu entry "Controller"Store devices in DPRO Controller: Online/Offline list of devicesDetailed report for non-available (offline) devicesRefresh buttonRestart option availableNetwork interface selection <p>Improvement</p> <ul style="list-style-type: none">mDNS speed improvements: bether/fatser device discoveryAdd monitoring of DPRO device heartbeatSort the device listHandling of network settings <p>Bug fixes</p> <ul style="list-style-type: none">Bad performance of discovery without DHCPAdaptions for MacOSXFocus on selected entry in a list with active scroll bar
1.2.0.0 03.11.2020	<p>Improvement</p> <ul style="list-style-type: none">Phantom power button only red when activeMUTE button only red when active <p>Bug fixes</p> <ul style="list-style-type: none">Discovery after IP (network) changeDevice can not be selected in list
1.1.0.0 27.08.2020	<p>Improvement</p> <ul style="list-style-type: none">Device detection - Detection process optimized <p>Bug fixes</p> <ul style="list-style-type: none">Graphic - Fixed tearing / glitches on Windows 10
1.0.0.0 27.08.2020	<p>Bug fixes</p> <ul style="list-style-type: none">DPRO Controller works without Dante Controller installation
1.0 02.10.2019	Initial release

LIECHTENSTEIN (HEADQUARTERS)

Neutrik AG, Im alten Riet 143, 9494 Schaan
T +423 237 24 24, F +423 232 53 93, neutrik@neutrik.com

GERMANY / NETHERLANDS / DENMARK / AUSTRIA

Neutrik Vertriebs GmbH, Felix-Wankel-Straße 1, 85221 Dachau, Germany
T +49 8131 28 08 90, neutrik@neutrik.de

GREAT BRITAIN

Neutrik (UK) Ltd., Westridge Business Park, Cothey Way
Ryde, Isle of Wight PO33 1 QT
T +44 1983 811 441, sales@neutrik.co.uk

FRANCE

Neutrik France SARL, 52 rue d'aguesseau, 1er etage, 92100 Boulogne-
Billancourt
T +33 1 41 31 67 50, info@neutrik.fr

USA

Neutrik USA Inc., 4115 Taggart Creek Road, Charlotte, North Carolina, 28208
T +1 704 972 3050, info@neutrikusa.com

JAPAN

Neutrik Limited, Yusen-Higashinohonbashi-Ekimae Bldg., 3-7-19
Higashinohonbashi, Chuo-ku, Tokyo 103
T +81 3 3663 47 33, mail@neutrik.co.jp

HONG KONG

Neutrik Hong Kong LTD., Suite 18, 7th Floor Shatin Galleria
Fotan, Shatin
T +852 2687 6055, sales@neutrik.com.hk

CHINA

Ningbo Neutrik Trading Co., Ltd., Shiqi Street, Yinxian Road West
Fengjia Villiage, Hai Shu District, Ningbo, Zhejiang, 315153
T +86 574 88250833, sales@neutrik.com.cn

ASSOCIATED COMPANIES

Contrik AG

Steinackerstrasse 35, 8902 Urdorf, Switzerland
T +41 44 736 50 10, contrik@contrik.ch

H. Adam GmbH

Felix-Wankel-Straße 1, 85221 Dachau, Germany
T +49 08131 28 08-0, anfrage@adam-gmbh.de



www.neutrik.com